



K00047 ADAPTER KIT

Installation Instructions

1. The K047 adapter kit is used for installing an E-0200, E-0400, or G-0600 ice machine on an SH-500 bin. The bin must be leveled before proceeding to step 2.
2. **INSTALLATION OF ASAPTER:**
 - A. Remove four screws from bin used to hold hinges.
 - B. Locate right-hand and left-hand adapter panels.
 - C. Remove foam tape, which is under the adapter panels.
 - D. Using panels as template, drill four holes, 5/32" diameter, in back of bin.
 - E. Secure panels in place.
 - F. Apply foam tape, as shown in Illustration 1.
3. **INSTALLATION OF ICE MACHINE:**
 - A. Remove two screws from bottom of ice machine that are 16 1/2" from the back of the machine.
 - B. Position ice machine on bin.
 - C. From inside the bin, reinstall the two screws removed in Step 3A.
 - D. Proceed to service manual for electrical and water hook-up and start-up procedures.